

# RDT-RF



Mains Recessed RF Room Thermostat  
Installation and Operation Guide

# Table of contents

<b>Installation Instructions</b>	
Factory Default Settings	3
Specifications	4
LCD Display	5
Buttons	6
Wiring	7
Mounting & Installation	8
<b>Operating Instructions</b>	
On / Off Function	12
Adjusting the Target Temperature	12
Locking the Keypad	12
Backlight	13
Menu	13
P0 1 Connecting a RDT-RF	14
P0 2 Operating Mode	16
Nor (Normal Mode)	17
Delay Start Control (On/Off)	18
Time Proportional Integral Mode (TPI)	20
P0 3 Setting High and Low Limits	23
P0 4 HYS - Hysteresis	24

P0 5 Calibrate	25
P0 7 Setback Mode	26
P0 8 AFS - Air / Floor Sensor	27
P0 9 FHL - Floor High Limit	29
Resetting the Thermostat	30



Mains Recessed RF Room Thermostat

**Installation Instructions**

## Factory Default Settings




Temperature indicator:	°C
Keypad lock:	Off
Backlight:	Auto
Operating mode:	Normal
High and low Limits:	OFF
Hysteresis:	0.4°C
Setback temperature:	0°C
AFS - Air / Floor / Sensor:	01 Internal Air Sensor
FHL - Floor High Limit:	26°C


## Specifications

Power supply / Input:	230VAC
Power consumption:	<1W
Temperature range:	5...35°C
Ambient temperature:	0...45°C
Ambient admissible humidity:	5-95% RH
Dimensions:	95 x 95 x 40mm
Internal temperature sensor:	NTC 100K
Backlight:	White
IP rating:	IP20
Pollution degree:	2
Hysteresis (Switching differential):	Adjustable from 0 to 1°C 0.1°C increments
Automatic action:	1C
Setback temperature:	Adjustable 0 to 10°C

# LCD Display




# Buttons





## Wiring



### Terminal Connections

L	Live In
N	Neutral In
1 & 2	External air sensor
3 & 4	External floor sensor

**Note:** NTC10K temperature sensor can be bought separately as an accessory.

## Mounting & Installation


### Caution!

- Installation and connection should only be carried out by a qualified person.
- Only qualified electricians or authorised service staff are permitted to open the thermostat.
- If the thermostat is used in a way not specified by the manufacturer, its safety may be impaired.
- Prior to setting the thermostat, it is necessary to complete all required settings described in this section.
- Before commencing installation, the thermostat must be first disconnected from the mains.

**This thermostat can be mounted to a 1 Gang recessed back box.**

- 1) Remove the thermostat from its packaging.
- 2) Choose a mounting location so that the thermostat can measure the room temperature as accurately as possible.
  - Mount the thermostat 1.5 meters above the floor level.
  - Prevent direct exposure to sunlight or other heating / cooling sources.
- 3) Press the fastening clip on the base of the thermostat to release the front housing from the rear wiring box as per diagram on page 10.
- 4) Wire the thermostat according to the wiring diagram on page 7.
- 5) Screw the rear wiring box to the recessed back box.
- 6) Attach the front housing to the rear wiring box until it clips securely into place.


1

UK  
CA


CE

Type  
1C  
EN60730IP20  
EN60529


2




3




4



5



6






Mains Recessed RF Room Thermostat

## Operating Instructions


## On / Off Function

Press  to turn the thermostat On or Off. When OFF is displayed on the screen the thermostat and zone will be set to OFF.


**Note:** If the zone is in the constant OFF mode and the ON/OFF button is pressed, this will change the mode of the zone to constant ON.

## Adjusting the Target Temperature



Press  to increase the target temperature from 5-35°C.


Press  or wait 5 seconds. The target temperature is now saved.



Press  to decrease the target temperature from 5-35°C.


Press  or wait 5 seconds. The target temperature is now saved.

## Locking the Keypad

To lock the thermostat, press and hold  and  for 10 seconds.

 will appear on the screen. The buttons are now disabled.

To unlock the thermostat, press and hold  and  for 10 seconds.

 will disappear from the screen. The buttons are now enabled.


## Backlight AUTO

There are three settings for selection.



'AUT' The backlight is on for 10 seconds when any button is pressed.


'On' The backlight is permanently on.

'OFF' The backlight is permanently off.

To adjust the backlight setting, press and hold  for 10 seconds.

'AUT' appears on the screen.

Use  and  to change the mode between AUTO, ON and OFF.

Press  to confirm selection and to return to normal operation.

## Menu

This menu allows the user to adjust additional functions.

Press and hold  and  together for 5 seconds to access the menu.

## P0 1 Connecting a RDT-RF


This function allows the user to connect a RDT-RF to a UFH10-RF or a R\_7-RF<sup>V2</sup> programmer.


### To connect a RDT-RF to a UFH10-RF

#### 1. On the UFH10-RF:

Press , 'P01 rF COn' will appear on the screen.

Press , 'RF CONNECT' will appear solid on the screen.

Rotate  to choose the zone you would like to connect to.

Press  to confirm. The zone will stop flashing and appear solid.


#### 2. On the RDT-RF:

Press and hold  and  together for 5 seconds.



'P01' will appear on the screen.

Press  to select.

Wait for 'r01' to appear solid.

Press  to confirm the thermostat is connected.

#### 3. On the UFH10-RF:

Rotate  to choose another zone you would like to connect to or press  twice to return to normal operation.

**Note:** When pairing additional zones to a UFH10-RF, 'r02', 'r03', 'r04' ... 'r10' can appear on the thermostat screen.



## Connecting a RDT-RF to a R\_7-RF<sup>V2</sup>

### 1. On the R\_7-RF<sup>V2</sup>:

Press  , 'P01 rF COn' will appear on the screen.

Press  , 'RF CONNECT' will appear solid on the screen.

### 2. On the RDT-RF:

Press and hold  and  together for 5 seconds.

'P01' will appear on the screen.

Press  to confirm.

### 3. On the R\_7-RF<sup>V2</sup>:

Once 'ZONE' flashes, press  on the desired zone.

### 4. On the RDT-RF:

Wait for 'r01' to appear.

Press  to confirm the thermostat is connected.

\*If there are multiple RDT2-RF to be connected, repeat steps 2, 3 and 4.

### 5. On the R\_7-RF<sup>V2</sup>:

Press  to return to the main screen when thermostat pairing is complete.

**Note:** When pairing additional zones to an R\_7-RF<sup>V2</sup>, 'r02', 'r03', 'r04' can appear on the thermostat screen.

## P0 2 Operating Mode (Normal / Delay Start / TPI)



There are three settings for selection, Normal, Delay Start or TPI mode. The default setting is Normal.

Press and hold  and  together for 5 seconds.

'P01' will appear on the screen.

Press  until 'P02' appears on the screen.

Press  to select.


Use  and  to select between:

**nOr** (Normal mode)

**dS** (Delay Start mode)

**tPi** (Time Proportional Integral mode)


Press  to confirm the mode.

Press  to return to normal operation.

## Nor (Normal Mode)

When the temperature falls below the target temperature, 🔥 will appear and the thermostat will activate the demand for heat.

When the temperature rises above the target temperature, 🔥 will disappear, and the thermostat will cancel the demand for heat.




## P0 2 Operating Mode continued

### Delay Start Control (On/Off)

When in this mode the thermostat is delayed by a variable time depending on the current temperature, target temperature and also the fall in temperature from when the delay start has activated. The 🔥 will flash until the thermostat activates.

When activated the thermostat will allow the heating system time to reach the target and delay start will remain inactive until it reaches this target.

Graph (18.1): Delay Start Control



E.g: If the temperature is 6°C below the thermostat target, the thermostat will call for heat immediately.

If the temperature is 2°C below the target, the thermostat will not call for heat for 32 minutes.

### Delay start can be reactivated by:

1. Press  to lower the target below the current temperature.
2. Press  to confirm.
3. Press  to increase the target temperature above the zone temperature within 6°C .
4. Press  to confirm.

The heating will be delayed as per the graph on page 18.

If the difference between the actual temperature and the target is 1°C the thermostat will delay starting for circa 40 minutes.

If the difference between the actual temperature and the target is 3°C the thermostat will delay starting for circa 24 minutes.

If the difference is 6°C or more then the thermostat will be switched on immediately.

The time delay will change if the temperature drops from the original calculation.

## P0 2 Operating Mode continued

### Time Proportional Integral Mode (TPI)

When the thermostat is in TPI mode and the temperature is rising in the zone and falls into the Proportional Bandwidth section, TPI will start to affect the thermostats operation. The thermostat will turn on and off as it gains heat so that it doesn't overshoot the target by too much. It will also turn on if the temperature is falling so it doesn't undershoot the target which will leave the user with a more comfortable level of heat.

There are 2 settings that will affect the thermostats operation.

1. The number of heating cycles per hour.
2. The Proportional Bandwidth.


### CyC – Number of Heating Cycles per hour 6 Cycles

This value will decide how often the thermostat will cycle the heating on and off when trying to achieve the target temperature. You can select 2, 3, 6 or 12.

## Pb -Proportional Bandwidth 2°C

This value refers to the temperature below the target at which the thermostat will start to operate in TPI control. You can set this temperature from 1.5°C to 3.0°C in 0.1°C increments.



Graph (21.1): TPI Control



## P0 2 Operating Mode continued



### Time Proportional Integral Mode (TPI)

Once TPI mode is selected, 'CYC' and '06' will appear on the screen.


Use  and  to select from 2, 3, 6 or 12.

Press  to confirm.

'P Band' and '2.0' will appear on the screen.

Use  and  to select from 1.5 to 3.0.


Press  to confirm.

Press  to return to normal operation.



## P0 3 Setting High & Low Limits OFF

This menu allows the installer to change the minimum and maximum temperatures that the thermostat can be set to between 5...35°C.

Press and hold  and  together for 5 seconds.

'P01' will appear on the screen.



Press  until 'P03 & LIMIT' appears on the screen.

Press  to select.

Use  and  to select 'ON'.



Press  to select.

'HIGH LIMIT' will appear on the screen, the temperature will begin to flash.


Use  and  to select the high limit for the thermostat.

Press  to confirm.

'LOW LIMIT' will appear on the screen, the temperature will begin to flash.

Use  and  to select the low limit for the thermostat.

Press  to confirm.

Press  to return to normal operation.

'LIMIT' will appear on the screen.

## P0 4 HYS - Hysteresis HYS On 0.4°C HYS OFF 0°C

This menu allows the installer to change the switching differential of the thermostat when the temperature is rising and falling.


If 'HYS ON' is set at 0.4°C and the setpoint is 20°C, then the thermostat will switch on when the temperature drops below 19.6°C.

If 'HYS OFF' is set at 0.2°C and the setpoint is 20°C, then the thermostat will switch off when the temperature reaches 20.2°C.



Press and hold  and  together for 5 seconds.


'P01' will appear on the screen.


Press  until 'P04 & HYS' appears on the screen.



Press  to select. 'HYS' & 'ON' will appear on the screen.

Press  and the 'HYS On' temperature will begin to flash.


Use  and  to select the 'HYS On' temperature.

Press  to confirm. 'HYS' & 'OFF' will appear on the screen.

Press  and the 'HYS OFF' temperature will begin to flash.

Use  and  to select the 'HYS OFF' temperature.

Press  to confirm.

Press  to return to normal operation.

## P05 Calibrate

This menu allows the installer to calibrate the temperature of the thermostat.

Press and hold  and  together for 5 seconds.

'P01' will appear on the screen.


Press  until 'P05 & CALIBRATE' appears on the screen.

Press  to select.

'CALIBRATE' and the actual temperature will appear on the screen.

Press  and  to calibrate the temperature.

Press  to confirm.


Press  to return to normal operation.

## P0 7 Setback Mode (0°C / Off)

In Setback mode, the thermostat reduces the temperature setpoint by 0°...10°C which is predetermined by the user. The factory default setting is set to (0°C / OFF) and needs to be activated to function. Setback mode will only work when the zone is timed off. This can only happen when the zone is in the AUTO OFF or ALL DAY OFF mode.

Press and hold  and  together for 5 seconds.

'P01' will appear on the screen.



Press  until 'P07 & SB' appears on the screen.

Press  to select. 'OFF' will appear on the screen.


Use  and  to select 'On'.

Press  to confirm.

The setback temperature will begin flashing on the screen.

Use  and  to select setback temperature between 0°...10°C.

Press  to confirm.

Press  to return to normal operation.

The setback temperature will be saved and the user will be returned to the previous screen.

When in Setback mode 'SB' will appear on the screen.

## **P0 8 AFS - Air / Floor Sensor** (01 Internal air sensor)

This function allows the user to select between 5 different temperature sensor options.

### **01 Internal air sensor**

This option allows the user to record the room temperature using the internal sensor. This is the default option.

### **02 External air sensor**

This option allows the user to record the temperature of an adjacent room. **(NTC10K temperature sensor required).**

### **03 Floor sensor**

This option allows the user to record the temperature of the floor using the external sensor only. This will prevent the floor from overheating. **(NTC10K temperature sensor required).**

### **04 Internal air sensor with an external high limit sensor**

This option allows the user to record the room temperature with the internal sensor while having the external sensor record the floor temperature to prevent overheating. **(NTC10K temperature sensor required).**


## P08 AFS - Air / Floor Sensor Continued

### 05 External air sensor with an external high limit sensor

This option allows the user to record the room temperature with external sensor 1 while having external sensor 2 record the floor temperature to prevent overheating. **(NTC10K temperature sensors required).**

Press and hold the  and  together for 5 seconds.

'P01' will appear on the screen.


Press  until 'P08' appears on the screen.

Press  to select.

'01' will flash on the screen.

Use  and  to choose between options 01, 02, 03, 04 or 05.

Press  to confirm.

Press  to return to normal operation.

**Note:** NTC10K temperature sensor can be bought separately as an accessory.


## P09 FHL - Floor High Limit 26.0°C

This function allows the user to select the high limit temperature of the external sensor. Selectable temperature range 5°C – 45°C.

**Temperature Sensor 04 or 05 must be selected, See Page 27 & 28 P07 AFS.**



Press and hold  and  together for 5 seconds.

'P01' will appear on the screen.


Press  until 'P08' appears on the screen.

Press  to select.

The high limit temperature will flash on the screen.

Use  and  to choose the desired high limit temperature.

Press  to confirm.

Press  to return to normal operation.

## Resetting the Thermostat

To reset the thermostat to factory settings.

Press and hold  and  together for 5 seconds.

'P01' will appear on the screen.

Press  until 'RST' appears on the screen.

Press  to select.

'NO' will flash on the screen.

Press .

'YES' will flash on the screen.

Press  to confirm.

The thermostat will restart and revert to its factory settings.









## EPH Controls IE

technical@ephcontrols.com

[www.ephcontrols.com/contact-us](http://www.ephcontrols.com/contact-us)

+353 21 471 8440

Cork, T12 W665



## EPH Controls UK

technical@ephcontrols.co.uk

[www.ephcontrols.co.uk/contact-us](http://www.ephcontrols.co.uk/contact-us)

+44 1933 322 072

Harrow, HA1 1BD

