CR221PRF / CR222PRF / CR228PRF
S Plan Wireless Pack

Wiring Diagram

Components:

1 x 2 Channel Wireless Programmer
2 x 2 Port Motorised Valve
1 x Wireless Room Thermostat
1 x Wireless Cylinder Thermostat
1 x Wiring Centre

CAUTION!

Consult the boiler installation instructions before wiring!

Boiler manufacturers wiring schematics may vary:

- A permanent power supply may be required
- An overrun function may be required
- A volt-free signal from the motorised valves limit switches may be required

SPUR FUSED @ 3A



R27-RF^{V2}

Wireless Programmer



RFR^{V2}

Room Thermostat

HEATING VALVE (ZV1)



RFC^{V2}

Cylinder Thermostat

HEATING VALVE (ZV2)



WIRING CENTRE



BOILER



PUMP