CR3PRUF / CR322PURF / CR328PURF
3 Channel Wireless Pack

Wiring Diagram

Components:

1 x 3 Zone Wireless Programmer
2 x 2 Port Motorised Valves
2 x Wireless Room Thermostat
1 x Wiring Centre

CAUTION!

Consult the boiler installation instructions before wiring!

Boiler manufacturers wiring schematics may vary:

- A permanent power supply may be required
- An overrun function may be required
- A volt-free signal from the motorised valves limit switches may be required

SPUR FUSED @ 3A

R37-RF[V2]

Programmer



RFR[V2]

Room Thermostat (1)

RFR[V2]

Room Thermostat (2)



HEATING VALVE (ZV1)

HEATING VALVE (ZV2)

WIRING CENTRE



BOILER



PUMP

EPH CONTROLS

EPH Controls Ireland
technical@ephcontrols.com www.ephcontrols.com

EPH Controls UK
technical@ephcontrols.co.uk www.ephcontrols.co.uk