CR4PRF / CR422PRF / CR428PRF
4 Channel Wireless Pack

Wiring Diagram

Components:

1 x 4 Zone Wireless Programmer
4 x 2 Port Motorised Valves
3 x Wireless Room Thermostat
1 x Wireless Cylinder Thermostat
1 x Wiring Centre

CAUTION!

Consult the boiler installation instructions before wiring!

Boiler manufacturers wiring schematics may vary:

- A permanent power supply may be required
- An overrun function may be required
- A volt-free signal from the motorised valves limit switches may be required

SPUR FUSED @ 3A

RFR[V2]

Room Thermostat (1)

RFR[V2]

Room Thermostat (2)

RFR[V2]

Room Thermostat (3)

RFC[V2]

Cylinder Thermostat

R47-RF[V2]

Programmer





WIRING CENTRE



BOILER



PUMP

HEATING VALVE (ZV1)



HEATING VALVE (ZV2)



HEATING VALVE (ZV3)



HEATING VALVE (ZV4)



EPH CONTROLS

EPH Controls Ireland
technical@ephcontrols.com www.ephcontrols.com

EPH Controls UK
technical@ephcontrols.co.uk www.ephcontrols.co.uk