TRFPi2 Room Thermostat Wireless

BOILER PLUS

Installation Instructions

For use in normal environments.

CAUTION! Installation and connection should only be carried out by a qualified person.

- Only qualified electricians or authorised service staff are permitted to open the thermostat.
- If the thermostat is used in a way not specified by the manufacturer, its safety may be impaired.
- Prior to setting the thermostat, it is neccessary to complete all required settings described in the section.

This thermostat can be mounted in the following ways:

1) To a recessed conduit box **2)** To a surface mounted box **3)** Directly mounted on wall

Important: Keep this document

1



2



3



4



5



6